



PreFormed Seats

DS-PREFSEATS-070814

Data Sheets are subject to change without notice. For latest revision, visit our website at www.finpan.com

1. PRODUCT NAME

Fin Pan PreFormed Seats

2. MANUFACTURER

Fin Pan, Inc.

3255 Symmes Road

Hamilton, OH 45015

Telephone: 1-513-870-9200

Toll Free: 1-800-833-6444

Fax: 1-513-870-9606

Internet www.finpan.com

3. PRODUCT DESCRIPTION

PreFormed Seats are constructed of lightweight high-density expanded polystyrene and a liquid waterproof membrane finish. PreFormed Seats are 100% waterproof and ready-to-tile.

Materials: Mortar mix for leveling pan area, ½" x ½" notched trowel, polyurethane adhesive/sealant for adhering seat to studs and waterproofing joints. Modified thinset for setting tile or stone.

Advantages

- Lightweight and durable.
- Factory installed, code approved waterproofing meets ANSI A118.10 requirements
- Ready-to-tile
- Fin Pan 20-Year Limited Warranty

Uses

- Interior and Exterior
- Showers and tub surrounds.
- Residential and commercial

Suitable Substrates

- Walls: Cement Backer Board or equal
- Floors: Mud-bed or preformed shower pans

PreFormed Seat Models

PF-402 Triangle/16" x 16" x 20"

PF-403 Triangle/23" x 23" x 20"

PF-404 Triangle Convex/16" x 16" x 20"

PF-414 Square/12" x 12" x 18"

Shelf Life

- Factory sealed boxes are guaranteed to be of first quality for five (5) years if stored at temperatures >32°F (0°C) and <100°F (43°C).

Limitations

- Mastics and silicones are never to be used.
- Don't expose to rubber solvents or ketones.
- Don't expose to sun or weather.
- Must be covered with ceramic tile or stone
- Surfaces must be structurally sound, stable and rigid enough to support ceramic/stone tile, thin brick and similar finishes.

Cautions

Consult MSDS for safety information.

- If waterproof coating on the PreFormed Seat is punctured during installation re-coat the punctured area and 2" (50 mm) around the area with two coats of a liquid waterproofing.

4. TECHNICAL DATA

Waterproofing membrane meets ANSI A118.10

5. INSTALLATION

PREPATORY WORK

- Shower should be waterproofed in accordance with Tile Council of North America (TCNA) guidelines and all other applicable local codes before installing seat.
- Ensure that walls are square and plumb for proper fit.
- Area where seat is to be installed must be level in order for seat to fit the walls. Use leveling mortar mix in area where seat is to be installed.
- Test fit seat to ensure proper fit against wall area.
- Adjust as necessary.

INSTALLATION

- Apply a medium bed, modified thinset to the floor under and walls behind the seat. Use a ½" x ½" notched trowel. On the wall, trowel thinset horizontally.
- Slide seat in the thin-set, flattening the ridges and ensuring complete coverage of thin-set.
- Once seat is installed, use a polyurethane adhesive/sealant on all joints where seat meets the walls. Alternatively, apply fiberglass mesh and a liquid waterproof membrane.

Tile Installation Detail

- Install tile using a modified thinset and in accordance with the Tile Council of North America (TCNA) guidelines.

6. AVAILABILITY AND COST

Availability

Fin Pan products are available worldwide.

For Distributor information call:

Toll Free: 1-800-833-6444

Telephone: 1-513-870-9200

Cost: Contact a Fin Pan Distributor in your area

7. WARRANTY

Contact Fin Pan

8. MAINTENANCE

PreFormed Seats require no maintenance.

9. TECHNICAL SERVICES

Technical Assistance

Information is available by calling Fin Pan Monday thru Friday from 8:00 AM to 5:00 PM EST.

Technical and Safety Literature

Please visit our website at www.finpan.com.

10. FILING SYSTEM

Information is available at www.finpan.com.

DS-PREFSEAT-070814